

PHONE: 1-800-734-6268

www.shuttercontractor.com

Vinyl ReNu Application Instructions

Vinyl ReNu is a revolutionary product that can restore your faded or oxidized vinyl siding to like new appearance. We recommend you use the following procedure for best results. It is not necessary to remove the vinyl siding from the house to use this product.

Improper surface preparation is the cause of most failures. Ensure that the cleaner is diluted properly, is not allowed to dry on the surface and is completely rinsed. Failure to follow the cleaning instructions may cause poor results. Cleaning the vinyl siding surface with anything other than the provided cleaner may cause premature failure. Any residual oils, chemicals, bug sprays, etc. left on the vinyl siding surface after cleaning may result in a failed application.

Vinyl ReNu Cleaner Concentrate

The first step is to ensure the surface of your vinyl siding is thoroughly cleaned using the Vinyl ReNu cleaner concentrate. The Vinyl ReNu cleaner contains no solvents (VOCs).

- 1. Dilute the cleaner using 10 parts clean water and 1 part cleaner. Well water should be distilled first to prevent it from causing mineral deposits on the surface.
- 2. To remove oxidization, the surface must be agitated with a soft bristle brush. Be sure to coat the entire surface of the vinyl siding with cleaner. DO NOT ALLOW CLEANER TO DRY ON SURFACE. We recommend cleaning no more than about 10 square feet at a time and rinsing before proceeding to keep the cleaner from drying on the surface.
- 3. Rinse thoroughly with clean water. Be sure to remove all of the cleaner any residue can cause discoloration when the Vinyl ReNu Surface Shield is applied later.

Vinyl ReNu Surface Shield

After your vinyl siding has been cleaned using the above procedure allow it to dry thoroughly before proceeding.

- Use a high-quality paint brush to apply Vinyl ReNu Surface Shield. No taping off is necessary. Any Vinyl ReNu that gets on windows should be cleaned quickly. Any Vinyl ReNu that gets on other surfaces can be allowed to dry clear or rinsed with water quickly after accidental application.
- 2. Apply a second coat of Vinyl ReNu after the first coat is completely dry.

Page 1 of 3



PHONE: 1-800-734-6268

www.shuttercontractor.com

Vinyl ReNu

Long Term Care Instructions

Cleaning your vinyl siding after the application of Vinyl ReNu should be done by spraying the vinyl siding with water from a garden hose once per year. If you need more aggressive cleaning, dilute the Vinyl ReNu Cleaner with water to a ratio of 20:1 and clean with a soft cloth.

If your vinyl siding begins to fade again, simply clean the surface and re-apply Vinyl ReNu.

Be sure that you do not let the sprinklers hit the surface of your vinyl siding, as this could cause it to discolor over time. Once the Vinyl ReNu coating is discolored, the vinyl siding must be painted using a vinyl safe paint.

Any use of chemicals, solvents, bug sprays, etc. after application may cause premature failure or discoloration.

Before using, consult Material Safety Data Sheet for further information and precautions, and can be obtained by contacting us toll free at (888) 219-9411 or by e-mail request at info@vinylrenu.com. Manufacturers Liability limited to purchase price of this product. USE ONLY AS DIRECTED.

PRECAUTIONARY STATEMENTS:

CAUTION: Use only in well ventilated areas. Eye and skin irritant. Do not get in eyes or on skin. Wear goggles or face shield and chemical resistant rubber gloves and boots when using this product. May be harmful if swallowed.

Vinyl ReNu Cleaner Practical Treatments

IF INHALED: If breathing becomes difficult, move person from contamination area to fresh air. **IF IN EYES:** Flush with plenty of water for at least 15 minutes. Get medical attention if irritation persists.

IF ON SKIN: Wash skin with soap and water. Remove and wash contaminated clothing before reuse. Get medical attention if irritation persists.



PHONE: 1-800-734-6268

www.shuttercontractor.com

IF SWALLOWED: Drink 1 or 2 glasses of water. Call a physician immediately.

Vinyl ReNu Surface Shield Practical Treatments

IF INHALED: Immediately remove person to fresh air. If breathing has stopped, begin artificial respiration. If breathing is difficult, administer oxygen. If symptoms develop and persist, obtain medical attention.

IF IN EYES: Immediately flush eyes with running water for a minimum of 15 minutes. Obtain medical attention immediately.

IF ON SKIN: Wash skin thoroughly with mild soap and water, while removing contaminated clothing. Obtain medical attention if irritation persists. Launder clothing before reuse.

IF INGESTED: Do not induce vomiting. Obtain medical attention. Never give anything by mouth to an unconscious or convulsing person.

ENVIRONMETAL HAZARDS: This product is toxic to fish. Do not allow liquid residue or product to contaminate estuaries, streams, lakes or other waters. Keep effluent out of sewer systems.