

Shutter ReNu

Application Instructions

Shutter ReNu is a revolutionary product that can restore your faded or oxidized exterior vinyl shutters to like new appearance. We recommend you use the following procedure for best results. It is not necessary to remove the vinyl shutters from the house to use this product.

Improper surface preparation is the cause of most failures. Ensure that the cleaner is diluted properly, is not allowed to dry on the surface and is completely rinsed. Failure to follow the cleaning instructions may cause poor results. Cleaning the vinyl shutter surface with anything other than the provided cleaner may cause premature failure. Any residual oils, chemicals, bug sprays, etc. left on the vinyl shutter surface after cleaning may result in a failed application.

Shutter ReNu Cleaner Concentrate

The first step is to ensure the surface of your vinyl shutters is thoroughly cleaned using the Shutter ReNu cleaner concentrate. The Shutter ReNu cleaner contains no solvents (VOCs).

1. Dilute the cleaner using 10 parts clean water and 1 part cleaner. Well water should be distilled first to prevent it from causing mineral deposits on the surface.
2. To remove oxidization, the surface must be agitated with a soft bristle brush. Be sure to coat the entire surface of the shutter with cleaner. **DO NOT ALLOW CLEANER TO DRY ON SURFACE.** We recommend cleaning no more than 1 pair of vinyl shutters at a time and rinsing before proceeding to keep the cleaner from drying on the surface.
3. Rinse thoroughly with clean water. Be sure to remove all of the cleaner – any residue can cause discoloration when the Shutter ReNu Surface Shield is applied later.

Shutter ReNu Surface Shield

After your vinyl shutters have been cleaned using the above procedure allow them to dry thoroughly before proceeding.

1. Use a high-quality paint brush to apply Shutter ReNu Surface Shield. No taping off is necessary, however if your vinyl shutters are installed over faded vinyl siding, note that the siding will also change in color if Shutter ReNu is accidentally applied. Any Shutter ReNu that gets on windows should be cleaned quickly. Any Shutter ReNu that gets on other surfaces can be allowed to dry clear or rinsed with water quickly after accidental application.
2. Apply a second coat of Shutter ReNu after the first coat is completely dry.



11021 WILLINGHAM DRIVE • HUNTSVILLE, AL 35803 • PHONE: 1-888-778-4774

<http://www.shuttercontractor.com>

Your Shutter ReNu kit will restore approximately 14 shutters (7 pairs) of average size.

Long Term Care Instructions

Cleaning your vinyl shutters after the application of Shutter ReNu should be done by spraying them with water from a garden hose once per year. If you need more aggressive cleaning, dilute the Shutter ReNu Cleaner with water to a ratio of 20:1 and clean with a soft cloth.

If your shutters begin to fade again, simply clean the surface and re-apply Shutter ReNu.

Be sure that you do not let the sprinklers hit the surface of your shutters, as this could cause them to discolor over time. Once the coating is discolored, the vinyl shutters must be painted using a vinyl safe paint.

Any use of chemicals, solvents, bug sprays, etc. after application may cause premature failure or discoloration.

Before using, consult Material Safety Data Sheet for further information and precautions, and can be obtained by contacting us toll free at (888) 219-9411 or by e-mail request at info@shutterrenu.com. Manufacturers Liability limited to purchase price of this product. USE ONLY AS DIRECTED.

PRECAUTIONARY STATEMENTS:

CAUTION: Use only in well ventilated areas. Eye and skin irritant. Do not get in eyes or on skin. Wear goggles or face shield and chemical resistant rubber gloves and boots when using this product. May be harmful if swallowed.

Shutter ReNu Cleaner Practical Treatments

IF INHALED: If breathing becomes difficult, move person from contamination area to fresh air.

IF IN EYES: Flush with plenty of water for at least 15 minutes. Get medical attention if irritation persists.

IF ON SKIN: Wash skin with soap and water. Remove and wash contaminated clothing before reuse. Get medical attention if irritation persists.

<http://www.shuttercontractor.com>

IF SWALLOWED: Drink 1 or 2 glasses of water. Call a physician immediately.

Shutter ReNu Surface Shield Practical Treatments

IF INHALED: Immediately remove person to fresh air. If breathing has stopped, begin artificial respiration. If breathing is difficult, administer oxygen. If symptoms develop and persist, obtain medical attention.

IF IN EYES: Immediately flush eyes with running water for a minimum of 15 minutes. Obtain medical attention immediately.

IF ON SKIN: Wash skin thoroughly with mild soap and water, while removing contaminated clothing. Obtain medical attention if irritation persists. Launder clothing before reuse.

IF INGESTED: Do not induce vomiting. Obtain medical attention. Never give anything by mouth to an unconscious or convulsing person.

ENVIRONMENTAL HAZARDS: This product is toxic to fish. Do not allow liquid residue or product to contaminate estuaries, streams, lakes or other waters. Keep effluent out of sewer systems.